

HOW TO

REPAIR DAMAGED CONCRETE



1. Good preparation is vital. Start by removing any loose materials from the area that needs repairing.
2. Dampen the area before pouring the quick repair concrete in place.
3. Simply pour the content of the tub or bag into the damaged area, spread and level the concrete using a straight edge such as a trowel, float or piece of wood.
4. Using a watering can and rose attachment, sprinkle with clean water without causing excessive water to pond on the surface.
5. Using your straight edge, compact and smooth finish and leave to set for around 30 minutes.
6. Sprinkle again with clean water after around two hours.
7. Clean your tools immediately and leave the area tidy.



WHAT YOU NEED

MATERIALS

- Repair Concrete

TOOLS

- Hand Pointing Trowel
- Brick Hammer
- Watering Can

TECHNICAL HELPDESK

Tel: 0845 812 6232

E-mail: info-cement@tarmac.com

ONLINE

Scan the QR code to visit our website at <https://tarmac-bluecircle.co.uk>, packed full of information and video guides for DIYers.

